

BUTTON NAVIGATION



- 1 Incoming call or voicemail indicator
- 2 Line buttons
- 3 Softkeys
- 4 Navigation
- 5 Hold, Transfer, and Conference
- 6 Headset, Speakerphone, and Mute
- 7 Voicemail, Applications, and Directory
- 8 Volume

MODEL NOTE:
Your issued model of phone may not have the Line Buttons or the Headset option (7811). All other functionality is the same between the 78xx series phones.

NAVIGATION

LINE BUTTONS: Line buttons are located on both sides of the phone screen. Buttons that are not assigned to phone lines can be used for speed-dials and other features.

SOFT KEYS: Four softkeys buttons are located below the phone screen. You can press the more softkey (when available) to reveal additional softkeys.



HOW DO I SCROLL IN A LIST OR MENU?
Press up or down on the select bar.



A scroll bar on the screen indicates your relative position within in a list.



If you need additional assistance please contact the SAISD Service Desk.








Phone: 210.244.2929

Self service portal:
tinyurl.com/SAISDTechSupport



How do I select an item in a list or menu? With the item highlighted, press the Select button in the middle of the Navigation bar. Or, use your keypad to enter the corresponding item number.










COMMON PHONE TASKS

Place a call	Go off-hook before or after dialing a number.	Hold and resume a call	Press  , to hold a call and press it again to resume the held call.
Redial a number	Press Redial.	Transfer a call to a new number	Press  , enter the number, then press it again. <i>*Note: Calls cannot be transferred outside the district.</i>
Switch to handset during a call	Pick up the handset.	Start a standard conference call	Press  , dial the participant, then press it again.
Switch to speaker or headset during a call	Press  or  (if you have that function), then hang up the handset.	Silence the ring for an incoming call	Press the Volume button down once.
Mute and un-mute a call	Press 		
View call history	Press  > Call History.		

NOTES:



- Must dial 9 first to reach an outside line.
- Can only make local phone calls (210 and 726 area codes)

PHONE SCREEN ICONS

	Off-hook		Incoming call		Placed call
	On-hook		Missed call		Call on hold/resume call
	Connected call		Received call		Message waiting

SOFTKEYS

Softkey options that appear on screen will vary depending on which function is currently being used.

All Calls	Lists all missed, placed, and received calls.	Exit	Return to the previous screen.
Answer	Answer a call.	Fwd All/Fwd OFF	Setup/cancel call forwarding.
Apply	Confirm a ringtone selection.	Missed	Open the record of missed calls.
Call	Initiate a call.	More	Display additional softkeys.
Callback	Receive notification when a busy extension becomes available.	New Call	Make a new call.
Cancel	Cancel an action or exit a screen without applying changes.	OK	Confirm a selection.
Clear	Clear all values.	Park	Store a call.
Delete	Delete an entry from Call History.	Play	Play ringtone.
Del Call	Delete a call from Call History.	Redial	Redial the most recently dialed number.
Details	Opens the Details for a multiparty call in the Missed, Placed, and Received Call records.	Save	Save the chosen settings.
Dial	Dial a selected number.	Search	Search for a directory listing.
Divert	Send or redirect a call to voicemail or to a predetermined phone number.	Select	Select the highlighted option.
EditDial	Modify a number.	Set	Set a ringtone.
		Submit	Enter user information.
		>>	Move through entered characters.
			Backspace to delete characters.
			Back.